

## AIR UNIT FIRMWARE UPDATE INSTRUCTIONS

Download the STM32Cube programmer from [this page](#)

Run SetupSTM32CubeProgrammer\_win64.exe and continue with all the default options.



Insert the USB.

Make sure the Air Unit is not connected to power and connect it to your computer via a USB-USB cable (if your Air Unit has a mini-usb port, please connect it using a USB-miniUSB cable instead).




Open STM32CubeProgrammer, it should have an icon on the Desktop

Click the blue button left of "Connect" and select USB




There should be one device, USB1




Click "Connect", it should connect and display the contents of the controller


Click "Open File" (screen 9) and select the .hex file



The .hex should be loaded now and you can press "Download" (screen 10)



It should only take a few seconds to complete



Remove the USB and connect a MOBY device. Navigate to the menu -> system information to validate the AirUnit's firmware version.